

RÖCHLING news & knowledge

June | 2011

Polystone® M XDT - the industry's first X-ray detectable UHMW-PE!



Polystone® M XDT

Röchling Engineering Plastics continues to set trends and provide solutions in the food processing and pharmaceutical industries when it comes to product safety and quality assurance — announcing the first X-ray detectable UHMW-PE available in the market.

Repeated handling, cleaning and normal wear and tear of plastic component parts on food, beverage and pharmaceutical processing machinery increases the risk of a fragment breaking off and contaminating the product during processing.

The need for traceable plastics, especially machined parts for filling, sorting and packaging machinery is critical due to strict FDA regulations regarding foreign materials and contaminants. Since we introduced our line of Metal Detectable engineering plastics (Polystone® M MDT (UHMW-PE) and Sustarin® C MDT (Acetal)) more than two years ago, these unique products continue be an effective solution for plastic parts used in open product zone applications.

However moving forward, we quickly realized a demand for X-ray detectable plastic parts for today's high speed machinery as processors turn to X-ray inspection equipment especially for post-package inspection.

Working together with one of the world's largest food processors and a leading manufacturer of X-ray inspection systems, our **Polystone® M XDT** has proven to be detected with a particle size as small as a 3mm cube. Running at speeds as fast as 250 feet-per-minute, this product can be detected and automatically sorted to a product hold area for further inspection. It works effectively with various types of packaging including metal cans, plastic and composite containers and glass jars.

Coming soon, **Sustarin® C XDT Acetal** – the industry's first X-ray detectable Acetal specifically designed for food processing and pharmaceutical applications.



Polystone® M XDT can be detected as small as a 3mm cube.

It is the responsibility of the user to test and approve the detection of this product due to variations in x-ray detection systems and required sensitivity settings.

Available as:

Rods: ½" to 6" dia. Sheets: 3/8" to 4" thick



Röchling Engineering Plastics offers the most comprehensive product line in the USA & Canada including:

Polystone® M (UHMW-PE) Polystone® P (Polypropylene) Polystone® G (HDPE)

Sustamid[®] Nylon Sustarin[®] Acetal Susta HPMs

Applications

- ⇒ Scraper blades
- ⇒ Filler plates
- Pocket fillers
- Piston fillers
- Mixer Components
- Wear plates
- Volumetric fillers
- Hopper guides
- Baffles
- Pillow blocks
- Cups & Sleeves
- Dividers

Röchling Engineering Plastics

903 Gastonia Technology Parkway

Dallas, NC 28034, USA Phone: 704-922-7814 Fax: 704-922-7651

info@roechling-plastics.us www.roechling-plastics.us